

Ruth – Freestanding

Installation instructions

Included in the package:

- (1) Ruth table light fixture
- (1) Power Supply 24V, 65W

No Tools required

NOTE: Shade is not adjustable

How to install:

1. Remove the light from the box and place on desired surface.
2. Plug the light into the provided power supply and plug the power supply into a 120V source.

To Operate:

- Touch the light post anywhere above the line on the post to operate (Fig. 1). A quick touch will turn the light on and off.

To Adjust Brightness:

- Touching and holding the light post anywhere above the line on the post (Fig. 1) will adjust the continuous dimming feature.


NOTICE:

Class I Laser Device

Pulse duration: 50 ms

Emitted Wavelength: 940 nm

IEC 60825-1: 2014



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an outlet on a circuit different from that to which the receiver is connected, or consult the dealer or an experienced radio/TV technician for help.

Ruth – Surface Mount

Installation Instructions

Included in the package:

- (1) Ruth table light fixture
- (1) Surface Mount Clamp (if ordered)
- (2) ¼"-20 Button Head Screws
- (1) Power Supply 24V, 65W

Tools Required:

- 3-1/2" diameter hole saw (if needed)
- 5/32" Allen wrench

NOTE: Shade is not adjustable

How to Install:

NOTE: The surface mount is designed to fit a 3-1/2" diameter hole in a worksurface. If there is not a hole already in place, cut one before removing the light from the package.

1. Remove the light from the box and route the power cord through the hole in the worksurface, place the lamp into the hole, being mindful to not pinch the cord.

- USB version: Rotate the light so the USB ports are in the desired location relative to the worksurface.

TIP: It can be helpful to have a second person hold the light in place while clamping to ensure orientation stays as desired and the light does not fall over.

2. From the underside of the worksurface, install the lower clamp using the provided 1/4"-20 Button Head Screws. Refer to Figs. 1 and 2 for exploded and cross section views showing how the clamp is oriented. Using a 5/32" Allen wrench, tighten the two screws until the clamp is pressed firmly against the underside of the worksurface.

3. Plug the light into the provided power supply and plug the power supply into a 120V source.

To Operate:

- Touch the light post anywhere above the line on the post to operate (Fig. 1). A quick touch will turn the light on and off.

To Adjust Brightness:

- Touching and holding the light post anywhere above the line on the post (Fig. 1) will adjust the continuous dimming feature.

