# L/GHTCORP

### TUCK Installation Instructions

- Tuck fixture
- On/off/dimmer pack
- (2) adhesive cord managers

#### Mounting the fixture:

#### MAGNET MOUNT APPLICATION

#### CAUTION: Magnetic field present in magnet mount fixture.

- 1. Fixture comes with magnet/screw mounts pre-attached to the fixture. To attach directly to a metal surface, simply locate the fixture to the desired position (Fig. 1) and set in place (Fig. 2).
- 2. Plug DC cord to the on/off/dimmer pack end of the fixture and route to power supply (Fig. 3).
- 3. Plug power supply into 120V, 60Hz grounded outlet.

#### SCREW MOUNT APPLICATION

- 1. Remove magnet/screw mounts by carefully prying up one edge of the mount.
- 2. Using the included screws, screw bracket clip to shelf in desired location (Fig. 4) evenly spaced across the fixture and centered direction (Fig. 5).
- 3. Raise fixture to clip, aligning the channel on the back of fixture with clip and snap into place (Figs. 6 and 7).
- 4. Plug DC cord to the on/off/dimmer pack end of the fixture and route to power supply (Fig. 3).
- 5. Plug power supply into 120V, 60Hz grounded outlet.

#### Installing the cord managers:

Affix to clean, dry surface using firm, direct pressure for 3-5 seconds to achieve a good adhesion to mounting surface.

#### **Dimming**:

Touch and hold your finger to the on/off/dimmer pack. The fixture will brighten and then dim. Release the touch pad when preferred level of brightness is obtained. Each time the fixture is turned on it will return to the level of brightness that was previously set. To reset the brightness to a different level, simply touch and hold the touch pad.

#### Interconnecting Multiple Fixtures:

- 1. Route the interconnect cord from one end of a fixture to the end of an adjacent fixture (Fig. 8). The maximum distance between the interconnected fixtures is approximately 18", determined by the length of the interconnect cord provided, excluding the connectors.
- 2. Plug power supply into 120V, 60Hz grounded outlet.
- 3. Route the low power DC cord from power supply to the starter fixture.

NOTE: A 40-watt power supply is required when connecting multiple fixtures. All connected fixtures are controlled by the starter fixture's on/off/dimmer pack. Do not kink or pinch cords while routing, which may cause damage to the cord. When connecting more than one fixture, be sure to follow the interlinking









Fig. 4











## L/GHTCORP

connection table below for optimal performance. Only for use with the Tuck fixture manufactured by LightCorp. Max 36 watts total connected load. Cannot interconnect with any other product family.

#### **Interlink Combinations**

12"	17"	31"	44"
6	0	0	0
5	1	0	0
5	0	0	0
4	2	0	0
4	1	0	0
4	0	1	0
4	0	0	0
3	2	0	0
3	1	1	0
3	1	0	0
3	0	1	0
3	0	0	1
3	0	0	0
2	3	0	0
2	2	1	0
2	1	1	0
2	0	2	0
2	0	0	1
1	4	0	0
1	3	0	0
1	2	1	0
1	2	0	1
1	1	1	0
1	1	0	1
0	4	0	0
0	3	1	0
0	3	0	0
0	2	1	0
0	2	0	1
0	1	2	0
0	1	1	1
0	1	0	1
0	0	3	0
0	0	2	0
0	0	1	1
0	0	0	2

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protections against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver, Connect the equipment into an output on a circuit different from that to which the receiver is connected, or consult to dealer or an experienced radio/TV technician for help.









Fig. 8

